

* for staged capacity units, two values divided by a slash (/) will be declared in each box in the section 'Declared capacity of the unit' and 'Declared EER/COP' of the unit.